

Messenger Bags, Backpack, Diaper Bag and Wallet Transferring Instructions

Read these instructions completely before you begin.

Supplies Needed

- Messenger/Backpack/Diaper Bag/Wallet
- Heat Tape
- Heat Gloves

Step 1: Adjust the Heat Press

Oven Temperature: **400° F**
Dwell Time: **45 seconds**
Pressure: **Medium to Firm**



Note: These instructions, including transfer times and temperatures, are based on the inks, paper, ovens and products we use. Your inks, papers, etc. may require adjustments in your time/temp settings.

Step 2: Design and Print Your Transfers

Prepare your artwork in the normal way, taking into consideration the size of the imprintable flap. Bear in mind that you need to **mirror the image** to ensure it will be right-reading once it's printed. Most printers refer to this as "Flip Horizontal" or "Mirror".

Step 3: Transfer the Image

1. Place the transfer **face-down** against the flap, and secure it using heat resistant tape.
2. Place the flap on the heat press with the transfer on top.
3. Cover any exposed areas of the bag/wallet with plain paper to prevent scorching.
4. Press at **400° F** for **45 seconds** using **Medium to Firm** pressure.
5. Remove transfer while hot.

Note: For the wallet, do not attach Velcro to the printable flap until *after* printing. Then remove the paper-backing from the Velcro strip (which is already attached to the body of the wallet) and press firmly down in place.

Tips and Washing Instructions

- Use a wet cloth with mild detergent to gently wipe the surface of the bag.
- Bags should not be washed in the washing machine or soaked in water.

Customer Support

For support on these or any of our products, please call us toll-free for assistance: **877.795.1500**. You may also write to us at Support@LaserReproductions.com.