

Towel Transferring Instructions

Please read these instructions completely before you begin.

Supplies Needed

- Sublimatable Towel
- EZ-Trans Paper
- Light Adhesive Spray

Step 1: Adjust the Heat Press

Heat Press Temperature: **375° F**
Dwell Time: **35-40 seconds**
Pressure: **Medium-Firm**

***Note:** These instructions, including transfer times and temperatures, are based on the inks, paper, equipment, and supplies we use. Your inks, papers, etc. may require adjustments in your time/temp settings.*

Step 2: Design Your Transfer

Design your transfer in the usual manner.

Step 3: Transfer the Image

1. Spray a very light film of adhesive spray on transfer.
2. Stick transfer to towel panel, face down.
3. Place towel face up/transfer face down on the edge of the heat press so that only the printable area is on the heat bed (Fig. 1). Do not press the entire towel, as you could scorch the cotton parts.
4. Using **medium** to **firm** pressure, press at **375° F** for **35-40 seconds**. Peel immediately while the towel is hot.



Fig. 1

Tips & Techniques

You may tape edges of the white towel with heat tape so that there is no accidental transferring of the image other than on the polyester panel.

Customer Support

For support on these or any of our products, please call our toll-free number for assistance: **877.795.1500**. You may also write to us at support@laserreproductions.com.